

WPJ342 Hardware Manual



Copyright

This document contains information, which is protected by copyright. Reproduction, adaptation, or translation without prior permission is prohibited, except as allowed under the copyright laws.

© Copyright 2014 Compex Systems Pte Ltd.

All Rights Reserved.

Feedback

Please direct any comments or suggestions about this document to: feedback@compex.com.sg

Trademark Information

Compex® is a registered trademark of Compex Systems Pte Ltd. Microsoft Windows and the Windows logo are the trademarks of Microsoft Corp. All other brand and product names are trademarks or registered trademarks of their respective owners.

Disclaimer

Compex provides this manual without warranty of any kind, expressed or implied, including but not limited to the implied warranties of merchantability and fitness for a particular purpose. Compex may make improvements and/or changes to the product and/or specifications of the product described in this manual, without prior notice. Compex will not be liable for any technical inaccuracies or typographical errors found in this guide. Changes are periodically made to the information contained herein and will be incorporated into later versions of the manual. The information contained is subject to change without prior notice.

Publication date and version

Published 22th Sep 2014. Manual version 1.0.0.

Contents

COPYRIGHT	2
REVISION HISTORY	2
DEVELOPMENT KITS	2
BLOCK DIAGRAM	2
KEY FEATURES	3
<i>General Information</i>	3
<i>Information on Power</i>	3
CONFIGURATION AND INSTALLATION	4
<i>GPIO Bit Mapping</i>	4
<i>Interface Connectors</i>	4
<i>Serial Port Header</i>	5
<i>Serial Console Settings</i>	5
<i>Precaution when using Serial Converter</i>	5
<i>Serial Converter Pin Layouts</i>	6
<i>JTAG Port Header</i>	7
<i>Ethernet Connectors</i>	7
JTAG PROCESS	8
FIRMWARE	9
<i>CompexWRT Firmware</i>	9
<i>OpenWRT Firmware</i>	9
APPENDIX I	10
<i>Board Features</i>	10
<i>Top Side Of Board</i>	10
FAQ	12


REVISION HISTORY

Revision	Information / Changes
Rev 1.0.0	First release for WPJ342 BareBoard

DEVELOPMENT KITS

The Development Kits consist of JTAG and Serial Converter. Please contact our sales team at sales@compex.com.sg for a quotation.

BLOCK DIAGRAM



KEY FEATURES

General Information

PROCESSOR	Qualcomm Atheros AR9342[WASP Series]
MEMORY	64MB DDR2 SDRAM
NOR FLASH	NOR Flash 8MB (Up to 16MB max.)
PHYSICAL PORTS	9.2mm height mini-PCIE slot 2 FE ports with Auto-MDI/X
RADIO SUPPORTED	802.11a/b/g/n E.g. WLE200NX, WLE200N2-23, WLE200N5-23, WLE350NX
DEBUG INTERFACE	Serial (TTL) / JTAG (ARM-standard 14 pin) Optional JTAG Programmer**/ Serial Converter*** available
OPERATING TEMPERATURE	-20°C to 70°C
LED INDICATORS	7 LEDs total: Power, LAN, Signal LED 1,2,3,4/Diag
OTHER FEATURES	Push-Button Reset, Surge Arrestors, Buzzer*(Optional)
DIMENSIONS	95 mm x 105mm x 18 mm
ENCLOSURE	MML, MMJ, MMS

Information on Power

POWER OVER ETHERNET	(HV) Passive PoE: 24-48V, / IEEE 802.3af/at [Refer to Datasheet] (LV) Passive PoE: 9-24V(LV)
TYPICAL OPERATING POWER	4W (onboard standby) & 3.7W(no onboard radio)
DC SUPPLY	(HV)24V ~ 48V DC Supply (LV) 9V~24V DC
MINIPCIE SLOTS	Supported Voltages : 3.3V Supports all Compex WLE 11n Series

* Depend on Order Configuration.

** JTAG Programmer available to reprogram the flash in case of loader corruption.

*** Serial Converter available to change the TTL signals on board to RS232 signals for debugging.

CONFIGURATION AND INSTALLATION

GPIO Bit Mapping

GPIO Bit	Description	GPIO Bit	Description
0	JTAG TCK	9	UART_SIN
1	JTAG TDI	10	UART_SOUT
2	JTAG TDO	11	RSSI 1
3	JTAG TMS	12	RSSI 2
4	WLAN LED	13	RSSI 3
5	SPI_CS	14	RSSI 4
6	SPI_CLK	15	Buzzer Control
7	SPI_MI_SI	16	For Flash WP
8	SPI_MI_SO	17	Reset

Interface Connectors


The board interface connector pin assignments and signal descriptions are included in the following sections. The connectors are listed in the section below and the connector locations are shown in the following diagrams.

Connector	Function	Connector	Function
J1	LED Header	J31	USB signal
J3	JTAG Port	J32	Mini-PCIE Slot
J6	Power Jack	J33	Serial Port
P3/P5	Ethernet Ports	S1	Reset Button

Serial Port Header

The Serial Port (J23) Header signaling is shown in the following table.

Pin	Signal
1	VCC – 3.3V
2	UART 0 Transmit Data
3	UART 0 Receive Data
4	GND



Note:

Our Serial port Implementation requires an external high-impedance serial port not usually available with the serial ports of the notebooks/computers. You will need a Serial Converter available in the market. For our customers' convenience, it is bundled together with the board Development Kit.



Serial Console Settings

The serial console settings used together with the serial port is given below.

This serial port uses TTL signals, and therefore you have to use serial converter using MAX-211 IC (or other IC in the market that convert TTL signals to RS232 signals) in order to use it with the PC.

Baud Rate	115200
Data	8 Bit
Parity	None
Stop	1 Bit
Flow Control	None


Precaution when using Serial Converter

Please attach the serial converter first on the board serial header, before attaching the power supply. This is to ensure that there is no surge of power to the serial converter, and prevent any damage the chipset on the serial converter.


Serial Converter Pin Layouts

Cables on the serial converters are provided. You can use the 6 Pin (Fixed) to 4 Pin (Fixed) provided. The pin layouts of the serial converters for use with the board are as follows:

Pin Assignment (Serial Converters)	Signal (Serial Converters)	Connected to Pin on WPJ342	Signal (WPJ342)
Pin 1	VCC(3.3V) – Red	Pin 1	VCC (3.3V) – Red
Pin 2	TX – Orange	Pin 5	RX – Yellow
Pin 4	RX – Yellow	Pin 3	TX – Orange
Pin 6	GND – Green	Pin 7	GND – Green



Arrangement of Cables on Serial Converter to the board



Arrangement of Cables on the board itself


JTAG Port Header

The primary purpose of the board JTAG Port Header is to facilitate program download into Flash memory.

PIN	SIGNAL	PIN	SIGNAL
1	TRST_N	2	GND
3	TDI	4	GND
5	TDO	6	GND
7	TMS	8	GND
9	TCK	10	GND
11	RESET	12	NC
13	DINT	14	3V3

Note:

Normally, it has a JTAG Programmer compatible with the board. It is bundled with the board Development Kit. This JTAG programmer is able to download file onto the Flash, and thus recover a corrupted loader.



Ethernet Connectors

The board contains 2 X 10/100Base-T Ethernet Channels. The Ethernet Channels are available through standard 8-pin RJ45 connectors.

Ethernet Connectors(P1/P2) signals is shown below.

PIN	SIGNAL	PIN	SIGNAL
1	TX+/POE+	5	TX-/POE+
2	TX-/POE+	6	RX-/POE-
3	RX+/POE-	7	RX+/POE-
4	TX+/POE+	8	RX-/POE-


JTAG PROCESS

Minimum Requirement


1. OCD Commander Ver2.5.4
2. upbios.tst file (same for all Compex device)
3. uboot.bin file
4. JTAG cable

Steps


1. Install the OCD Commander to your PC
2. Plug the JTAG cable to the JTAG port of the device
3. Run OCD Commander Program, Set "Target Processor" for the particular device, Click "OK"
4. If there is this error message "Error Response from INITIALIZE....", please check the JTAG cable connection. Close the OCD Commander Program and go back to Step 3.



5. Click on the "Macro" and choose a specific .mac file.



6. Let it run until u see "go"



7. Open command prompt
8. tftp upbios.tst
9. tftp uboot.bin (please observe the DIAG LED is off)
10. If either step 9 or step 10 fail, please start from step 3 again.
11. Power off the device and unplug JTAG cable
12. Power on the device and tftp the firmware into the device.
13. Reboot when done.

FIRMWARE

CompexWRT Firmware

CompexWRT is a combination of advanced Qualcomm Atheros wireless driver into OpenWRT latest Attitude Adjustment 12.09, with the open-source Luci webpages. All the features have been tested and customers are able to put in “packages” from the OpenWRT into CompexWRT easily with the SDK provided.

CompexWRT Firmware: Please download from www.compex.com.sg

CompexWRT Firmware (with no Compex Logo): Please contact the sales person in charge for your account.

CompexWRT Usermanual: Please download from www.compex.com.sg

CompexWRT SDK: Please contact the sales person in charge for your account.

OpenWRT Firmware

OpenWRT Firmware is supported on this board. We provide an SDK and instruction on how to compile the SDK on our webpage.


OpenWRT+ath9K Firmware: Please download from www.compex.com.sg, after registration.

OpenWRT SDK: Please download from www.compex.com.sg, after registration.

OpenWRT Build Instructions and FAQ Please download from www.compex.com.sg, after registration.

Appendix I

Board Features



Top Side Of Board

No	Feature	Descriptions
1	Reset button	For board reset and startup mode control
2	DC Jack	(HV) 24V ~ 48V DC Supply (need 802.3af module, refer to datasheet) (LV) 9V~24V DC
3	LAN port	①10/100 Base T Ethernet port - PoE Input . ②Can change to WAN port in CompexWRT firmware. (HV) This port do not support high voltage POE (LV) 24V POE
4	LAN port	①10/100 Base T Ethernet port - PoE Input. ②Can change to WAN port in CompexWRT firmware. (HV) 24V ~ 48V passive POE and .3af POE (LV) 24V POE

5	Serial port	Serial port connection header
6	mini-PCIE slot	9.2mm height mini-PCIE slot
7	USB Pin	Support USB Port and USB Extension
8	Radio	5GHz On-board radio(23dBm/perchain)
9	AR9342	Main Chipset
10	JTAG port	JTAG jumper header for programming

FAQ

1. The Ethernet ports are two LAN port in default, WAN port is defined by software, so you can change any Ethernet port to WAN port in Luci interface.
2. There is only one eth port (far away from DC Jack) supports High voltage passive PoE or 802.3af/at PoE in HV version of WPJ342.